

Note: Using An External Temperature Probe with Vantage Connect®

You may use an external temperature probe (product numbers 6475 or 6477) with your wireless Vantage Connect. Just feed the probe cable up through one of the holes in the bottom of the shelter (using the oval split grommet provided in the Vantage Connect hardware kit) and plug it into the cabled ISS jack. (See page 7.) This reading will replace the Vantage Connect's "inside temperature" reading.

Jack for External
Temperature Probe
(or for cabled ISS)

